

## **IMPORTANT!**

### **Special Installation Instructions for Active Diapason Antenna 868 MHz for Operations with Open Glider Network Software (<http://glidernet.org>)**

#### **Antenna Exchange**

- Switch off your Receiver/ USB Dongle Installation
- Wire the Active Diapason Antenna 868 MHz and the Bias Tee according to the Quickstart Guide
- Swap the existing antenna with the Active Diapason Antenna 868 MHz on the MCX connector
- Plug the Bias Tee USB power cable into a receiver's USB slot
- Restart your Receiver/ USB Dongle Installation
- No further action required

#### **First Time Installation**

When installing a new Receiver/ USB Dongle with an Active Diapason Antenna 868 MHz it is necessary to perform the USB Dongle calibration with a broadband antenna to detect GSM signals. Due to its filter characteristics the Active Diapason Antenna 868 MHz cannot detect GSM signals.

- Connect a broadband antenna to the USB dongle, like the small indoor antenna that comes with it or any other broadband antenna
- Perform the complete installation process per <http://wiki.glidernet.org/links#toc6> with the small indoor antenna or any other broadband antenna
- Proceed as per „Antenna Exchange“ above